Ares Note User Instructions

1, Features

1.1 Home

Home is the default main interface, features include: status bar, function bar, quotations, read statistics chart, recently used applications, and recently read books.

1.1.1 Status Bar

Click the refresh icon on the left status bar, you can freely switch to A2 refresh mode; click the multitask icon to manage the background applications, switch application or close and other operations.

Click the right status bar to show the menu of switches and notifications, including the backlight, volume, contrast adjustment, WiFi, Bluetooth. Long press WiFi, Bluetooth, the percentage of the battery can enter the corresponding detail setting. If the system displays a message to remind the "Notice" window, click on the top right of the Clear icon in the notification window to clear the notification information.

1.1.2, function bar

Home features include bar, shelves, application.

1.1.3, Quotations

Users can customize quotation, click on the quotation, you can enter the setting.

Click on any quotation,

[Edit] to enter edit mode, save, or cancel editing the text;

[Using] the quotations column presents selected;

Press Quotations perform delete operations.

1.1.4 Read statistics chart

Record the read statistics of recent day and one week.

1.1.5 Shortcut of recently used or favorite applications

The default setting is the recently used applications, and you can switch the setting in User settings.

1.1.6 Recently read & Recently added

User copied to the device will scan the books displayed in the [recent] add bar to open read the books will be displayed in the [recent] read the column.
In recently added or recently read , long press the book cover to show menu of book, author, book size, type of books, reading long, annotate article number, add reading progress, clear reading progress function, marked as read function, delete function and setting open function.

2.1, bookshelf

Bookshelf default shows the ebooks saved in the BOOKS directory in memory cards, and books transferred by WiFi book transfer application. Features include: setting of grids mode, book search, library management, bookshelves, books sorting and re-scan books.

Home : **Books** : Notes : App

	New	New	Book management
personal space	Young Folks' Library, Volume XI (of 20) ...	Favourite Fables in Prose and Verse	Bookshelf settings
			Book selection
			Rescan books
			Children's Hour with Red Riding Hood ...

0 personal space

New — Young Folks' Library, Volume XI (of 20) ...

New — Favourite Fables in Prose and Verse

Children's Hour with Red Riding Hood ...

New — Tales of Wonder Every Child Should ...

New — Stories from the Ballads, Told to the Ch...

New — Childhood's Favorites and Fairy Storie...

New — Good Cheer Stories Every Child Shoul...

New — Folk Tales Every Child Should Know

New — A Book of Natural History / Young Folks..

Total9books   1/1

2.1.1, Grids mode

The default is 12 grids shelves mode, click the top left set button switch   among list mode, tile mode and 9-grid mode.

2.1.2, Search

Click the search icon to enter search interface. Keyboard automatically opens, enter a search term, word association can automatically display the search results.

2.1.3, Library management

Features include deleting, moving, radio and select all, easy manage books, books can be moved to an existing folder or a new folder, you can reach move books function in the menu of books via long press book cover.

2.1.4、 Books

Books menu allows to filter and sort appearance of the section.

2.1.5、　Book Rescanning

Click "rescan"to rescan books in the set paths　(the set path is consistent with the system settings).

3.1、Notes

Tap the "+" icon on the left to create new handwritten records.
　Tap the "More" icon on the right, then a list of new folder, batch management, sorting notes and settings will appear. All the notes you have created are visible in the section.
Tap and hold the note to rename, export,move to and delete.

3.1.1、Add Notes

After you tap the "+" icon, a tooltip window will appear.

Full page: Tap the icon, then the menu will be hidden. Tap the thumbnail on the left to restore the menu bar.

Pen: tap the icon to select the pen or ballpoint pen. Change color (black or white) by tapping the "bucket" icon.

Stroke thickness: click the icon to adjust the thinckness of the drawn line and the scope of area to erase.

Eraser: there are three different erasing tools.

Area eraser : use the pen to draw around the area you want to erase.

Regular eraser: lets you use the pen as an eraser.

Erase all: tap the icon to clear the whole page.

Choose: tap this icon to move, rotate, scale a drawn object.

Templates: tap the icon to choose the template you want to use.

AI recognition: click the icon to quickly convert your handwritten notes to typed text.

Undo: click undo to reverse your last action. Note that undo works untill all handwritten notes are undone.

Add layers: let you save multiple layers of handwritten notes.

Preview: click the page number to open the preview window where you can edit, delete or export the handwritten notes.

Jumping to a page: tap the page number shown in the status bar to jump to random pages.

More: click it to open a drop-down list of items including recovery undo, delete this page, copy this page,note search, ban mode, paste, and share export.

Recovery undo: click the icon to redo the action undone by the undo button. Note the icon

will be greyed out and do not work if nothing has been undone.

Delete this page: tap it to delete the current page. Note the icon will be greyed out and cannot work when there is only one handwritten page left.

Copy this page: tap the icon to create a copy of the current page and one more page will be added.

Note search: tap it to search for a note.

Ban mode: tap the ban mode icon to disable capacitive touch so that the touchscreen will not respond to human touch.

Export: the handwritten notes can be saved as PNG or PDF files and can be uploaded to Evernotes and Youdao cloud note. There is also an option for sharing your notes with other devices using a QR code.

Click file manager<root<note to view the handwritten notes that are imported to local PNG or PDF.

To successfully export Notes sent to Evernote, one needs to log into the Evernote acount with Internet connection.

Export notes

Page selection

O All pages   Current page

Note background

O Template   White

Export location

O To local PNG   To local PDF

Impression notes   YouDao Cloud Not

QR code sharing

Cancel   Export

3.1.2、Exit

Click the Exit icon, or press the back button and home button simultaneously to save your notes and exit the note-taking interface.

4.1、APP

The section shows all user-installed and system preset applications; the snowflake icon on the left is used to launch management, and the menu on the right includes items like "applications management" and "applications sort".

4.1.1、 Applications Management

Tap Applications Management to open the APK management interface where you can uninstall apps,clear application data and set up permissions, etc.

4.1.2、 Applications Sort

Tap this icon to sort all apps.

4.1.3、Press-and-hold

Press and hold a third-party app icon, then a new interface with setting options like full screen mode, A2 mode,bleaching function, use Regal to refresh, animation filtering delay, application refresh rate, image brightness adjustment, DPI adjustment and contrast adjustment will appear.

Cool Reader
3.1.2-102

Uninstall

Full screen mode
Full screen display when the app starts

☐

A2 mode
Faster refresh rate

☐

Bleaching function
Used for interfaces that are not compatible with the original black background

☐

Use Regal to refresh
More suitable for black and white interface, reducing afterimage

☐

Animation filtering delay
0 ms   — ⊙————————————— +

Application refresh rate
20   — ————————⊙———— +

Image brightness adjustment
0   — ⊙————————————— +

DPI adjustment(System default:240dpi)
240   — ———⊙—————————— +

Contrast adjustment
☑ Use system contrast
1   — ⊙————————————— +

5.1. Booking Uploading via WiFi

(1) Reader and computer are connected to the same network.

(2) Input the website address displayed in the Booking Uploading via WIFI interface to the computer, it can start uploading the book.

(3) After all the books on the web page are uploaded successfully, the device will return to the Bookshelf interface, and the books will be automatically added to the Bookshelf.

6.1. File Manager

The Home Page of File Manager displays the supported format category, click each category to display all the files under this category;

EPUB	TXT	PDF	MOBI
EPUB (263)	TXT (521)	PDF (117)	MOBI (358)
FB2	DOC	AZW	Picture
FB2 (4)	DOC (5)	AZW (13)	Picture (78)
Music	APK	Zip	
Music (63)	APK (19)	Zip (1)	

Internal Total:12.79GB Available:12.26GB

External Total:119.05GB Available:92.31GB

Click [This Device] to enter the File Manager, functions include: Search, New Folder, Viewing Mode, File Management;

6.1.1. Search

    Click the search icon and enter the Search interface. The keyboard is automatically turned on and the search results are available by entering search terms.

6.1.2. New Folder

   Create a new folder to sort and manage different files;

6.1.3 Viewing Mode

Users can set the display mode of the interface via [Icon Mode] and [Sort Mode]

6.1.4. File Management

Operations such as delete, copy, cut and paste can be performed.

7.1. Settings

Users can enter the settings page to complete all settings for the device, including WiFi, Bluetooth, Reading Settings, User Settings, Power Management, Device Settings, Applications, System Updates, About the Device, etc.

7.1.1. WiFi

Set up and connect the wifi network in this menu.

7.1.2. Bluetooth

Set up and connect the Bluetooth network in this menu.

7.1.3. Reading Settings

Users can have page turning mode settings and page refresh in this menu, which is consistent with the function in the reader.

7.1.4 User Settings

Users can have book catalog scanning settings, default main interface settings, home page shortcut application settings and wallpaper settings in this menu.

7.1.5. Power Management

Users can have sleeping time, shutdown time, WiFi automatic shutdown time setting in this menu.

7.1.6. Device Settings

Users can have screen locking password settings, language and input method settings, and restore factory settings in this menu.

7.1.7. Application

Users can uninstall APP, clear data and permission setting in this menu.

7.1.8. System Upgrade

Users can update the system version in this menu.

7.1.9. About the Device

Users can view the device model, device version number, serial number, device MAC address in this menu.

8.1. Reader

This device supports books in the following formats: TXT, EPUB, PDF, MOBI, AZW3.

Words can be selected in the Reading interface: By long pressing the words, the words are selected, then the dialog box will pop up with options such as settings, copy, underline, annotation, encyclopedia, dictionary;

Settings; Click and switch to the dictionary priority setting interface.

Copy Selected Words; After selecting on the dialog box, users can copy the selected content, long press the screen to paste the copied content in any editing interface;

Underline Selected Words; After selecting on the dialog box, the selected words display the underline;

Add annotation: After selecting on the dialog box, enter the interface to edit the annotation; after saving the annotation, the words will be highlighted, click on the highlighted part or enter the annotation list to view the annotation information;

Encyclopedia for Selected Words: After selecting the encyclopedia on the dialog box, users can search the selected words in the encyclopedia;

Translation for Selected Words: After selecting the dictionary on the dialog box, the translation function will start working. If the entry words exist in the device's thesaurus, there is a corresponding translation; if the entry words do not exist in the device's thesaurus, there is a corresponding prompt.

8.1.1. Reading Progress

Click the reading progress icon to adjust the backlight brightness, search keywords, enter the Table of Contents interface, and users can also adjust the progress bar at will or click the left and right buttons of the progress bar to view the previous chapter and the next chapter.

Library, Volume XI (of 20), by Various, Edited by Edward Singleton Holden

This eBook is for the use of anyone anywhere at no cost and with

almost no restrictions whatsoever. You may copy it, give it away or

re-use it under the terms of the Project Gutenberg License included

with this eBook or online at www.gutenberg.net

Title: Young Folks' Library, Volume XI (of 20)

Wonders of Earth, Sea and Sky

Author: Various

Editor: Edward Singleton Holden

Release Date: May 23, 2005 [eBook #15884]

Young Folks' Library, Volume XI (of 20) / Wonders of Earth, Sea and Sky

Page *1* （A total of *575* pages） 0.1%Readed

8.1.2. Format

Font Size: Click More Button on the right side of the menu to set the font size, users can set bold and italic (bold and italic require font support).
Typesetting: Click More Button on the right side of the menu to set line spacing, segment spacing, word
spacing, left and right spacing, and upper and lower spacing.
Contrast: Adjustable blackening of text and pictures.
Automatic Page Turning: Different time periods can be set for automatic page turning.
Horizontal Screen: Horizontal and vertical screen settings can be made.

8.1.3、Reading Settings

Page turning settings, page refresh settings, control operations and page settings can be made.

8.1.4、 Table of Contents

Click a chapter in the List interface to skip the page, switch menu to view bookmarks, underlined notes and annotations, export notes to impression notes.

8.2、 PDF Book Reading

The PDF typesetting functions include: Contrast, Typesetting Settings, De-watermarking, Horizontal Screen and Rearrangement. Other functions are consistent with the functions of EPUB books;

Contrast: Click More Button on the right side of the menu to adjust the contrast through grayscale and brightness;

Typesetting: Automatic trimming, manual trimming, full screen, reel, adaptive width, and

column.

De-watermarking: Watermarks from watermarked books can be removed.

Horizontal screen: Horizontal and vertical screen settings can be made.

typeset: Front size, Word spacing, row soacing, contrast can be set.

Note: The scanned version of PDF books does not support the words selection function.

The rearrangement function is mainly for the scanned version of PDF books.

8.2.1、PDF Handwriting Function

PDF Handwriting function include：ban mode, pen set, eraser, Handwritten notes on split screens, research all. double page reading mode

Ban mode: tap the ban mode icon to disable capacitive touch so that the touchscreen will not respond to human touch.

Pen: tap the icon to select the pen or ballpoint pen. Choose the line width. Change color (black or white) by tapping the"bucket"icon.

Eeaser：include"Stroke erasure" and "Ereser all"

Stroke erasure: lets you use the pen as an eraser

Ereser all: tap the icon to clear the whole page

Handwritten notes on split screens: can take notes while reading.

9.1 Dictionary

Supported dictionary formats: StarDict Dictionary, Mobi Dictionary

9.1.1、Dictionary Installation

Put the dictionary in the Dict folder under the root directory (if users can't find the Dict folder, it can be created manually).

9.1.2、Dictionary Use

Search words: Enter the words and then click Query;

Translation: Enter the text that needs to be translated in the source language, select the target language and then click Translate;

New words: All new words (that is, all the words that have been looked up); new words in the book (that is, words in the book that have been looked up).

Settings: Priority settings for word lookup dictionaries.

2. FAQ

2.1   How to Switch On/Off

In the shutdown state, press the On/Off Button for 2 to 3 seconds to enter the boot animation interface, and enter the operation interface after the progress is finished.

In the boot state, press the On/Off Button for 2 to 3 seconds, the system will pop up a dialog box indicating whether to shut down or not. Select yes and shut down.

2.2 How to Charge

Connect the device to computer USB for charging via the data cable;
Connect the USB and the device to the AC socket for charging via the adapter;
Direct charging will be faster than connecting the USB with computer.

2.3. How to Transmit Data

Connect the device and the computer for data transmission via USB data cable.

2.4. How to Upgrade

You can upgrade the software by following these steps;
- Download the card brush bag, copy the zip folder named update.zip to the device root directory, and enter the Settings System Update Menu. Click Local Detection Update and then click Install Now in the pop-up menu. The device will automatically restart and complete the update.
- Click Download in the pop-up prompt box. After the completion, the device will automatically restart and update. Note: please do not do anything during the upgrade, otherwise it may not be able to boot.

2.5. How to Set Up Standby Wallpaper (Photo size: 1404*1872)

You can set up standby wallpaper in the following two ways;
- Enter "Settings-User Settings-Wallpaper Settings-Custom Lock Screen Wallpaper" (Please put the wallpaper in the Wallpaper Folder under the root directory first)
- Enter the photo gallery, select and open the picture, and click the wallpaper icon in the upper right corner to set it to wallpaper.

2.6 How to Set Fonts

It is unable to set the system font for the time being. Please refer to "8.1.2 Layout [Font] Setting" for Reader Font Settings.

2.7   How to add bookmarks